
## **AURORA FIRE PUMPS**

FITTINGS FOR DIESEL FUEL TANKS

Section **916** Page **259** 

Date April 2009


Supersedes Section 916 Page 259 Dated November 2000




1, LOCKABLE FUEL CAP

6.25

4.75





2. SCREENED TANK VENT



19. EMERGENCY VENT

"A"	"⊟"	"C"	"D"
4"	7,00	3,78	6,44
6*	10,20	4,46	6,53






12. LOCKABLE FUEL VALVE

## NOTES

- 1. All dimensions are in inches and may vary  $\pm\ 1/4".$
- 2. Components shown are shipped loose for field assembly.
- 3. Illustration is for component identification only. Actual installation must meet local codes and all applicable standards.
- 4. Refer to Section 916 pages 255 through 258 for the location and applicability of each component shown above



14. FLAME RESISTANT FLEXIBLE FUEL HOSE(2) FURNISHED BY ENGINE MANUFACTURERFOR SUPPLY AND RETURN LINES

